
AGSTWC - 24VAC


OVERVIEW



SEQUENCE OF OPERATION

- 1. WATER SOLENOID VALVES.
- THIS SYSTEM USES NORMALLY OPEN WATER SOLENOID VALVES, WHICH MEANS THEY MUST BE ENERGIZED TO CLOSE.
- 2. "ON" BUTTON.
 - ENERGIZES THE WATER SOLENOID VALVE TO CLOSE FOR SET TIME FUNCTION.
- TIME FUNCTION MAY BE CHANGED OR DISABLED.
- 3. "OFF" BUTTON
- DE-ENERGIZES THE WATER SOLENOID VALVE TO RE-OPEN THE WATER SOLENOID VALVE.


WIRING



DETAIL - LAB WATER ON/OFF CONTROLLER 120VAC

AGSTWC - 120VAC


OVERVIEW



SEQUENCE OF OPERATION

- WATER SOLENOID VALVES.
- 1.1. THIS SYSTEM USES NORMALLY OPEN WATER SOLENOID VALVES, WHICH MEANS THEY MUST BE ENERGIZED TO CLOSE.
- "ON" BUTTON.
- 2.1. ENERGIZES THE WATER SOLENOID VALVE TO CLOSE FOR SET TIME FUNCTION.
- 2.2. TIME FUNCTION MAY BE CHANGED OR DISABLED.
- 3. "OFF" BUTTON
- 3.1. DE-ENERGIZES THE WATER SOLENOID VALVE TO RE-OPEN THE WATER SOLENOID VALVE.


WIRING



1 DETAIL - LAB WATER ON/OFF CONTROLLER 120VAC

MERLIN 500S - 120VAC


OVERVIEW



SEQUENCE OF OPERATION

- 1. SOLENOID VALVES
- THIS SYSTEM USES NORMALLY CLOSED SOLENOID VALVES, WHICH MEANS THEY MUST BE ENERGIZED OPEN.
- 2. KEY IN ON POSITION
- 2.1. VALVES ARE ENERGIZED OPEN BY 120VAC OUTPUT
- 3. KEY IN OFF POSITION
- 3.1. VALVES ARE DE-ENERGIZED
- 4. EMERGENCY INPUTS
- SYSTEM WILL DE-ENERGIZE THE SOLENOID VALVES AND DISPLAY EMERGENCY INPUT LED ON FRONT FASCIA
- MANUAL RESET REQUIRED VIA KEY TO RESTORE OPERATION
- 5. BMS OUT RELAY
- SWITCHES WHEN WATER IN ON/OFF OR WHEN SYSTEM WHEN EMERGENCY SHUTDOWN IS ACTIVATED.






DETAIL - LAB WATER ON/OFF CONTROLLER 120VAC

LIGHT SWITCH OPERATION


OVERVIEW



SEQUENCE OF OPERATION

- 1. WATER SOLENOID VALVES.
 - 1.1. THIS SYSTEM USES NORMALLY OPEN WATER SOLENOID VALVES, WHICH MEANS THEY MUST BE ENERGIZED TO CLOSE.
- 1.2. VALVES MUST BE AGS SOLVLV SERIES.
- 2. SWITCH ON.
- 2.1. ENERGIZES THE WATER SOLENOID VALVE TO CLOSE.
- 3. SWITCH OFF.
 - DE-ENERGIZES THE WATER SOLENOID VALVE TO RE-OPEN.

WIRING



1 DETAIL - LAB WATER ON/OFF SWITCH 120VAC