

## ALARM SELECTION GUIDE

### 1. SWITCH OFF POWER!

Unscrew the four bolts of the device using an M3 socket wrench.  
Carefully remove the front fascia to expose the circuit board.

### 2. SWITCH ON

### 3. PRESS TOUCH BUTTON for 3s to start warm-up.

### 4. PRESS & HOLD internal button during the initialization screen. The screen will display Model Selection.

### **BE CAREFUL OF LINE VOLTAGE CONNECTIONS**



### 5. TAP INTERNAL BUTTON to scroll through the Code Select options.

|                         | Selection  | Explanation                                                                                                                                     |
|-------------------------|------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>CODE SELECT &gt;</b> | <b>35</b>  | <b>CO Main Alarm @ 35ppm</b>                                                                                                                    |
|                         | <b>50</b>  | <b>CO Main Alarm @ 50ppm</b>                                                                                                                    |
|                         | <b>TWA</b> | <b>CO Main Alarm @</b><br>20ppm after two (2) Hours<br>50ppm after one (1) Hour<br>100ppm after ten (10) Minutes<br>300ppm after one (1) Minute |

### 6. SELECT CODE and wait for ~10 seconds.

### 7. SELECTION SAVED will display on screen.

### 8. UNIT WILL RESTART PRESS TOUCH BUTTON for 3s to start.

**info@americangassafety.com**